NEYCRAFT[™] CENTRIFUGAL CASTING MACHINE



Used to melt and cast metal into the replica investment cavity by centrifugal force, the patented Neycraft centrifugal casting machine is designed with a number of unique operating features.

- Built-in protective safety shield
- Easy winding/locking and release mechanism
- Instant balance with counterbalance weight
- Universal flask carriage to accommodate flasks up to 4" x 4" •
- Two-way mounting base for quick setup and storage

With the Neycraft centrifugal casting machine, you will be able to produce quality castings, safely,

Machine Set-up

- Crucible Installation: The machine ships completely assembled except for the installation of the crucible, which is simply installed by depressing the crucible clip and sliding the crucible into position against the crucible bracket.
- Mounting: The machine may be mounted to a solid, heavy bench or table either portably or permanently. No external shield or container is required for either type of mounting.

Balance

Balancing the machine is quick and simple. The machine is designed to be counterbalanced for three ranges of flask sizes: small, medium, and large. A 2.75 pound counterbalance weight is provided for installation in one of two position locating slots on the counterbalance arm.

Winding & Locking

An externally mounted knob is provided on the machine to allow you to wind and lock the machine while your hands are clear of the path or rotation of the casting machinery.

Maintenance

The only maintenance required on the machine is a periodic cleaning of the inside of the safety shell. After a period of time or a good number of casting cycles (this may vary from one week to several months, depending on the frequency of use), some debris will collect in the safety shell (investment powder, metal grains, flux, etc.). This debris should be removed by either vacuuming the shell interior or by turning the shell upside down and brushing out the interior. This periodic cleaning will prevent a build up of particles which could clog the crank handle locking mechanism.

For complete operation instructions, refer to the Neycraft centrifugal casting machine owner & operator's manual, available for download at: www.ransom-randolph.com.

As the conditions or methods of use are beyond our control, we do not assume any responsibility and expressly disclaim any liability for any use of this product. Information contained herein is believed to be true and accurate but all statements or suggestions are made without warranty, expressed or implied, regarding accuracy of the information, the hazards connected with the use of the material or the results to be obtained from the use thereof. Compliance with all applicable federal, state, and local regulations remains the responsibility of the user. All potential liability related to the sale and use of this product is limited to the cost of the particular goods sold in their respective transactions.



RANSOM & RANDOLPH

3535 Briarfield Boulevard | Maumee, OH 43537 USA 800.800.7496 | 419.865.9497 | 419.865.9997 (FAX) www.ransom-randolph.com fin

Made in the USA

Issue Date: September 22, 2023

Ransom & Randolph GmbH Leipziger Straße 40 | 04571 Rötha Germany +49 342 06373999 Investing with Innovation™